



A		4
B		1
C		1
D		1

STEP 1

Turn the chair upside down carefully and place it on a soft surface to prevent scratches.

STEP 2

Locate the bolts (A) that connect the base (D) to the top/seat (C).

STEP 3

Using the L-key (B), loosen and remove all bolts securing each leg to the seat.

STEP 4

Gently detach each leg from the seat once the bolts are fully removed.

STEP 5

Store all bolts (A) and base (D) together in a safe place for future re-assembly.