



**STEP 1**  
Pull out the cap.

**STEP 2**  
Open the wire in crown and separate the ribs.

**STEP 3**  
Open the wire in runner and separate the ribs.

**STEP 4**  
Remove the cover.

**STEP 5**  
Tap the joint knob and remove it.